

Elevator Air Conditioner 电梯空调



TK □ — □ □ Y/ □ □ □

- 1、电梯空调
- 2、冷暖机型
- 3、额定制冷量
- 4、控制方式
- 5、出风形式
- 6、电源类型
- 7、制冷剂类型



- 注1: 1) 字母“TK”: 表示电梯专用空调
- 注2: 1) 无字母: 表示单冷机型
2) 字母“D”: 表示冷暖机型
- 注3: 1) 数字“25”: 表示额定制冷量为2500W;
2) 数字“32”: 表示额定制冷量为3200W;
- 注4: 1) 字母“Y”: 表示遥控机型;
- 注5: 1) 无字母: 表示25(26)机下出风;
2) 字母“Q”: 表示空调器风口在前面;
- 注6: 1) 无字母: 为220~230V, 50Hz
2) 字母“W”: 为110V, 60HZ;
3) 字母“Z”: 为220V, 60HZ
- 注7: 1) 无字母: 表示制冷剂为R22;
2) 环保型制冷剂直接加后缀, 如“R410A”。
- 其他未列入的情况, 在型号后加文字说明。

- NOTE1: 1) Letter “TK” means: Elevator A/C;
- Note2: 1) No letter: only cooling function;
2) Letter “D”: cooling and heating double function;
- Note 3: 1) “25”: rated cooling capacity is 2500W;
2) “32”: rated cooling capacity is 3200W;
- Note 4: 1) Letter “Y”: remote controlled type;
- Note 5: 1) No letter: 25(26) cool air coming out from bottom;
2) Letter “Q”: cool air coming out from the front of the A/C;
- Note 6: 1) No letter: 220~230V, 50HZ;
2) Letter “W”: 110V 60HZ;
3) Letter “Z”: 220v 60HZ;
- Note 7: 1) No letter: R22 refrigerant;
2) Other refrigerant, add directly, such as R410A
- Other model not included will be explained by text