



TOBT-1



TOBT-2



TOBT-3



TOGS-2



TOGS-3



TOGS-4



TOGS-5



TOGS-6

TOGS-7



TOGS-8



TODS-1



TODV-1



TODV-2



TOHR-1



TOHR-2



TOHR-3



TOHR-4



TOHR-5



TOHR-6



TOHR-7



TOHR-8

SEES#	TOSHIBA#	产品描述	DESCRIPTION
TOBT-1		KA100 按钮	Push Button
TOBT-2		AK9701 按钮	Push Button
TOBT-3		AK9702 按钮	Push Button

SEES#	TOSHIBA#	产品描述	DESCRIPTION
TOGS-1		三合一靴衬 150×30×5 两片, 150×25×5 一片	Guide Shoe Insert Two 150×30×5, One 150×25×5
TOGS-2		三合一靴衬 220×45×9.3 两片, 220×34×8 一片	Guide Shoe Insert Two 220×45×9.3, One 220×34×8
TOGS-3		导轨 适用长度 200 的三合一靴衬	Guide Shoe Insert For Length=200
TOGS-4		导轨 86×17	Guide Shoe
TOGS-5		三合一靴衬 230×34×9.4 一片, 230×36×9.4 两片	Guide Shoe Insert one 230×34×9.4, Two 230×36×9.4
TOGS-6		三合一靴衬 150×36×5 两片, 150×26×5 一片	Guide Shoe Insert Two 150×36×5, One 150×26×5
TOGS-7		三合一靴衬 120×24×6 两片, 120×28×6 一片	Guide Shoe Insert Two 120×24×6, One 120×28×6
TOGS-8		导轨 靴衬长度 120	Guide Shoe Insert Guide Shoe Insert Length=120

SEES#	TOSHIBA#	产品描述	DESCRIPTION
TODS-1		门滑块	Door Slider 41×58×11

SEES#	TOSHIBA#	产品描述	DESCRIPTION
TODV-1		CV100、CV190 门刀轮	Door Vane 40×14 6201 ID:12
TODV-2		DZ100-190 门刀	Door Vane

SEES#	TOSHIBA#	产品描述	DESCRIPTION
TOHR-1		门挂轮	Hanger Roller Φ60×16 6203Z ID:17
TOHR-2		门挂轮	Hanger Roller 72×15 6202 GD:64.5 ID:15
TOHR-3		门挂轮	Hanger Roller 60×12 6200RZ GD:44 ID:10
TOHR-4		门挂轮	Hanger Roller 56×14 6201 GD:49 ID:12
TOHR-5		带偏轴门挂轮	Hanger Roller with Eccentric 60×16 6203 GD:52.1
TOHR-6		塑料门挂轮	Plastic Hanger Roller 75×18 6201 GD:68 ID:12
TOHR-7		门挂轮	Hanger Roller 62×16 6203 GD:53 ID:17
TOHR-8		门下轮	Under Hanger Roller 30×9 6g-M10
TOWH-3		塑料绳轮	Plastic Wheel 73×11 6200 ID:10
TOWH-4		塑料绳轮组件	Plastic Wheel Unit 73×11

SEES#	TOSHIBA#	产品描述	DESCRIPTION
TODH-1		CV100-190 东芝厅门挂板组件	Landing Door Hanger
TODH-2		CV100-190 东芝厅门挂板组件 带螺帽	Landing Door Hanger With Screw Cap

SEES#	TOSHIBA#	产品描述	DESCRIPTION
TOF-1	FV140	FV140 风机	Fan 115V, 220V

SEES#	TOSHIBA#	产品描述	DESCRIPTION
TOTR-1		曳引轮	Traction Sheave TM-5585 型 12×6

SEES#	TOSHIBA#	产品描述	DESCRIPTION
TODN-1		门缓冲胶豆	Door Rubber



TOWH-3

TOWH-4

TODH-1

TODH-2

TOF-1

TODN-1



TOLO-1W



TOLO-2



TOLO-4



TOLO-5



TOLO-5C



TOLO-6NC



TOPCB-5



TOPCB-8



TOPCB-10



TOPCB-14



TOPCB-19

SEES#	TOSHIBA#	产品描述	DESCRIPTION
TOLO-1R		CV55、CV60 门锁 右	Door Lock Right
TOLO-1W		CV55、CV60 门锁轮	Wheel Door Lock 40×20 ID:18
TOLO-1L		CV55、CV60 门锁 左	Door Lock Left
TOLO-2		CV100、CV190 门锁轮	Roller Door Lock 40×14 6201 ID:12
TOLO-3		门锁	Door Lock
TOLO-4		三角锁	Triangular Lock
TOLO-5		CV100 门锁	Door Lock
TOLO-5C		CV100 门锁触点	Door Contact
TOLO-6NO		限位开关 RLU1 常开	Limit Switch Normal Open
TOLO-6NC		限位开关 RLU1 常闭	Limit Switch Normal Close
TOLO-7NO		限位开关 QFU2 常开	Limit Switch Normal Open
TOLO-7NC		限位开关 QFU2 常闭	Limit Switch Normal Close

SEES#	TOSHIBA#	产品描述	DESCRIPTION
TOPCB-1		BCU-2N UCE6-13B 2N1M3161-A 驱动板	用于东芝 CV60 电梯 PC Board
TOPCB-2		BCU-2N UCE6-13B 2N1M3161-B 驱动板	用于东芝 CV60 电梯 PC Board
TOPCB-3		CCNU-NLB UCE1-308C3 2N1M3292-A	用于东芝 CV50 电梯 PC Board
TOPCB-4		CN-100A 电脑板	用于东芝 CV150、CV160 电梯 PC Board
TOPCB-5		COP-100L 电脑板	轿厢通讯板 用于东芝 CV180、CV190 电梯 PC Board
TOPCB-6		DCU-150	For CV150 PC Board
TOPCB-7		DIO-N	用于东芝 CV60 电梯 PC Board
TOPCB-8	5P1M1212P001C	HIB-100A SP1M1235-C UCE1-326C3	外呼板 用于东芝 CV180 电梯 PC Board
TOPCB-9		IO-150(UCE4-333L4 2N1M3296-A)	用于东芝 CV150 电梯 PC Board
TOPCB-10		IO-MLT	用于东芝 CV180、东芝 CV190 电梯 PC Board
TOPCB-11		IO-MLT2 副板	用于东芝 CV330、CV330A 电梯 PC Board
TOPCB-12	PM150CVA120	PM150CVA120 IPM	用于东芝 CV180 电梯 PC Board
TOPCB-13		LED-100A 显示器	用于东芝 CV180 电梯 PC Board
TOPCB-14	5P1M213P002-C	5P1M213P002-C LED-100B 显示器	用于东芝 CV180 电梯、UCE12-84A2 PC Board
TOPCB-15		MCU-VF-2A	速度控制板 用于东芝 CV60 电梯 PC Board
TOPCB-16		PU-200A 主板	用于东芝 CV150 电梯 PC Board
TOPCB-17		PU-MLT2 主板	用于东芝 CV330、CV330A PC Board
TOPCB-18		PU-MLT 主板	用于东芝 CV180、CV190 PC Board
TOPCB-19		VVV 门机调速器	东芝 CV180、CV190 电梯门机调速盒 Door Speed Control Board
TOPCB-20		LSIF 3UCE 4 CV60	PC Board
TOPCB-21		PUS 主板	PUI86-1A-UCE1-94C 2N1M3150-C MAIN BOARD
TOPCB-22		PU85-1A、UCE1-95CB、2N1M3152-C	东芝主板 Toshiba Main Board